

### Metals Test Package

Package includes: arsenic, copper, iron, lead, manganese, zinc.

Sample Drop Off Hours: Monday - Friday, 8:00am - 4:30pm

### Sample Collection Instructions

1. For a “flush” sample (testing the source water i.e. a well) turn the cold water for two to three minutes prior to proceeding to step 2. For a “first draw” sample (worst case scenario) proceed to step 2 after water has been stagnant for at least eight hours.
2. Open the 250 mL plastic bottle provided and fill the bottle to the shoulder.
3. Label the bottles with the date and time of collection.
4. Ship, mail, or transport the samples to the lab. (Please note: If you are shipping samples please be sure to cap tightly and pack securely to ensure the samples arrive intact. Packing tape around the caps can provide extra security. Shipping in a box rather than a bag also provides extra security.)

Standard turnaround time is ten business days. A final report will be e-mailed when all tests are completed.